

INSTALLATION INSTRUCTION

ULTRADUAL SL1 UNDERLAYMENT

1 SUBFLOOR PREPARATION

Clean, level, and dry the subfloor. Test concrete moisture level before starting.

3/4" plywood or concrete subfloor recommended.

2 POSITIONING

Start in a corner with the tape strip toward the wall. Run seams perpendicular to the planned plank direction.

3 UNROLLING

Unroll ULTRADUAL SL1 with the printed side facing UP. Lay flat without stretching.

4 TRIMMING

Trim the perimeter edges with a utility knife.

Maintain a 1/4" gap from all walls.

5 SEAMING — LIP & TAPE

Join rows using the built-in self-sealing lip & tape system. Only the moisture-barrier lip overlaps — foam edges must butt together, never overlap.

6 ALTERNATIVE SEAMING

If the lip-and-tape edge is unavailable (cut rows), butt the seams and seal with moisture-resistant single-faced tape.

7 FINAL INSTALLATION

Install the floor covering directly over the underlayment. Follow the flooring manufacturer's installation instructions.

PRODUCT SPECIFICATIONS

Product	ULTRADUAL SL1
Roll Size	3.61ft x 29.86ft x 3mm
Coverage	108 sq.ft / roll
Application	FOR ENGINEERED WOOD AND LAMINATE FLOORING