

INSTALLATION INSTRUCTION

ULTRAFLOW BD6 UNDERLAYMENT

1 CONFIRM COMPATIBILITY

Use only where the exact flooring manufacturer's instructions permit or require a separate 6 mil polyethylene moisture barrier.

2 PREPARE THE SUBFLOOR

Make sure the substrate is structurally sound, clean, dry, flat, and free of debris or sharp projections. Complete required moisture testing before installation.

3 ROLL OUT THE FILM

Unroll ULTRAFLOW BD6 without stretching. Cut each run slightly longer than the room so the film can turn up at perimeter walls.

4 OVERLAP ADJACENT RUNS

Lay the next sheet with a minimum 3 in (76 mm) overlap, unless the flooring instructions specify a different overlap.

5 SEAL EVERY SEAM

Peel the white release liner and press the integrated tape edge firmly along the full overlap. Keep the film continuous around penetrations and transitions.

6 INSPECT AND REPAIR

Protect the film from punctures. Seal cut ends and patch every tear or damaged area with compatible moisture-resistant tape before covering it.

7 INSTALL THE FLOOR

Install the approved floating floor according to its manufacturer instructions. Trim the perimeter turn-up only as directed by the flooring system guide.

PRODUCT SPECIFICATIONS

Product	ULTRAFLOW BD6
Roll Size	4ft x 25ft x 6 mil / 0.15mm
Coverage	100 sq.ft / roll
Application	FOR APPROVED FLOATING FLOORS OVER PROPERLY PREPARED SUBFLOORS